

RTM-ATCA-F125 Quick Start Guide

P/N: 6806800M56C December 2019

1 Box contents

Make sure you receive all items of your shipment:

- One RTM-ATCA-F125
- One printed copy of Quick Start Guide (this document)
- One printed copy of Safety Notes Summary
- Other items that were ordered



When installing or servicing the system or accessories, strictly observe the safety precautions in the *Safety Notes Summary*. Ignoring these instructions can void the system warranty and cause personal injury or property damage.

2 ESD

Use ESD protection



Electrostatic discharge and incorrect installation or removal of the card can damage circuit or shorten its life.

Use a properly grounded ESD wrist strap or work in an ESD-safe environment.

Connect to the ESD connector at the front or the rear of the system.

3 Site preparation

- Make sure that all environmental and power requirements defined in the *RTM-ATCA-F125 Installation and Use* manual are met.
- Operating temperatures refer to the temperature of the air circulating around the blade and not to the actual component temperature.

4 Install the RTM

1. Visually inspect the RTM-ATCA-F125 and zone 3 connectors on the front blade for damage or bent pins before attempting to insert a board.
If any connector damage or pin damage is observed, stop before inserting the RTM and send the damaged item through proper repair channels.
2. If the corresponding front blade is already installed, perform the following steps. Otherwise, proceed to step 3.
3. On the front blade, verify the face plate screws that secure the blade to the shelf are tight.
4. Deactivate the front blade. Unlatch the lower handle by squeezing the lever and the latch together and turning the handle outward only enough to unlatch the handle from the face plate. Do not rotate the handle fully outward.
5. When the blue LED on the front blade is permanently illuminated, proceed to the next step.
6. Ensure that the top and bottom ejector handles on the RTM are in the outward position by squeezing the lever and the latch together.
7. Insert the RTM into the shelf by placing the top and bottom edges of the RTM in the card guides of the shelf. Ensure that the guiding module of the front blade and RTM are aligned properly.
8. Apply equal and steady pressure to the RTM to carefully slide the RTM into the shelf until you feel resistance.

9. Continue to gently push the RTM until the connectors engage.
10. Squeeze the lever and the latch together and hook the lower and
11. the upper handle into the shelf rail recesses.
12. Fully insert the blade and lock it to the shelf by squeezing the lever and the latch together and turning the handles towards the face plate.
13. Tighten the face plate screws which secure the RTM to the shelf.
14. If the front blade has already been installed (as in step 2), activate the front blade by squeezing its lower lever and latch together and press it back into the face plate.
15. If the front blade has not been installed, proceed with the installation instructions in the front blade installation and use manual.



Make sure that the handles of both the RTM and the front blade are closed in order to power up the blade and RTM payload.

Note: When the RTM's blue LED is switched OFF and the green OK LED is switched ON, this indicates that the RTM's payload has been powered up and that the RTM is active.

16. Connect cables to the face plate, if applicable.

For more information about connecting cables and power cords, refer to the *RTM-ATCA-F125 Installation and Use* manual.



RTM-ATCA-F125 Quick Start Guide

Technical Assistance

For technical assistance or to report product damage or shortages, contact your local SMART Embedded Computing sales representative or visit <https://www.smartembedded.com/ec/support/>

Get More Information



For more information on this product, see the *RTM-ATCA-F125 Installation and Use* manual and other related technical documentation, which can be found by using the Documentation Search at <https://www.smartembedded.com/ec/support/>.

© 2019 SMART Embedded Computing™, Inc. All rights reserved. The stylized “S” and “SMART” is a registered trademark of SMART Modular Technologies, Inc. and “SMART Embedded Computing” and the SMART Embedded Computing logo are trademarks of SMART Modular Technologies, Inc. All other names and logos referred to are trade names, trademarks, or registered trademarks of their respective owners. These materials are provided by SMART Embedded Computing as a service to its customers and may be used for informational purposes only. For full legal terms and conditions, visit www.smartembedded.com/ec/legal.