



SMART[™]
Embedded Computing

SE1710 SMART Edge Server

Quick Reference

P/N: 6806800V34A

August 2020

Make sure you receive all items of your shipment:

- One SE1710 SMART Edge Server (1U, 19" rack mountable server)
- One power cable
- Mounting brackets
- One printed copy of the Quick Reference (this document)
- One printed copy of the Safety Notes Summary



When installing or servicing the system or accessories, strictly observe the safety precautions in the Safety Notes Summary. Ignoring these instructions can void the system warranty and cause personal injury or property damage.

Use ESD
protection



Electrostatic discharge and incorrect installation or removal of the card can damage Use a properly grounded ESD wrist strap or work in an ESD-safe environment.

GET MORE INFORMATION

For more information, see the SE1710 SMART Edge Server Getting Started Guide.

<https://qrqo.page.link/Fk1DG>



TECHNICAL ASSISTANCE

For technical assistance or to report product damage or shortages, contact your local SMART Embedded Computing sales representative or visit <https://www.smartembedded.com/ec/support/>.

© 2020 SMART Embedded Computing[™], Inc. All rights reserved. The stylized “S” and “SMART” is a registered trademark of SMART Modular Technologies, Inc. and “SMART Embedded Computing” and the SMART Embedded Computing logo are trademarks of SMART Modular Technologies, Inc. All other names and logos referred to are trade names, trademarks, or registered trademarks of their respective owners. These materials are provided by SMART Embedded Computing as a service to its customers and may be used for informational purposes only. For full legal terms and conditions, visit www.smartembedded.com/ec/legal.

SMART Embedded Computing, Inc.

2900 S. Diablo Way, Suite 190

Tempe, Arizona 85282 USA