

Centellis 2x00 User Card-10GE Quick Start Guide

P/N: 6806800K80C January 2020

1 Box contents

Make sure you receive all items of your shipment:

- One Centellis 2x00 User Card-10GE
- One printed copy of Safety Notes Summary
- Any optional items ordered



When installing or servicing the system or accessories, strictly observe the safety precautions in the *Safety Notes Summary*. Ignoring these instructions can void the system warranty and cause personal injury or property damage.

2 ESD

Use ESD protection



Electrostatic discharge and incorrect installation or removal of the card can damage circuit or shorten its life.

Use a properly grounded ESD wrist strap or work in an ESD-safe environment.

Connect to the ESD connector at the front or the rear of the system.

3 Site preparation

1. Make sure that all environmental and power requirements defined in the *Centellis 2x00 User Card-10GE Installation and Use* manual are met.
2. Leave enough space around the cabinet. Prevent air blocking of fans and provide controlled ambient air at shelf air-inlet to ensure sufficient airflow and appropriate heat exchange in the shelf.
3. Consider heat dissipation when you choose slots to install blades. If the shelf is not fully configured, install the blades in scattered slots. Unoccupied slots must be protected with appropriate blank filler blades to prevent air leaks.

4 Installing an SFP/SFP+ module

The following procedure describes how to install an SFP/SFP+ Module:

1. Slide the SFP/SFP+ module into the slot until it locks into position.
2. Remove the optical port plug.



SFP/SFP+ Module Damage

The optical port plug protects the sensitive optical fibers against dirt and damage. Dirt and damage can render the SFP/SFP+ module inoperable.

Only remove the optical plug when you are ready to connect a cable to the SFP/SFP+ module. When no cable is connected, cover the port with an optical port plug.

3. Connect the network cable to the SFP/SFP+ module.

5 Installing the user card

The following procedure describes the installation of the board. It assumes that your system is powered. If your system is not powered, you can disregard the blue LED and thus skip the respective step. In this case it is a purely mechanical installation.

1. Put on an ESD wrist strap.
2. Connect the strap to the shelf by attaching the front or rear ESD jack /ESD snap.
3. Insert the board into the shelf by placing the left and right edges of the board in the card guides of the shelf. Ensure that the guiding module of shelf and board are aligned properly. The alignment pin facilitates the insertion and prevents bent pins.
4. Slide the board into the shelf by using the extraction handles until you feel resistance.
5. Wait until the blue LED is illuminated.
6. Tighten the screws on the left and on the right of the board. In this way the handle switch activator is closed and the board can be powered. The blue LED blinks.
7. Wait until the blue LED is switched off.
8. The switched off blue LED indicates that the board is activated.
9. Attach cables to the front panel connectors as necessary.

6 Removing the user card

The following procedure describes how to remove the board from a system. It assumes that the system is powered. If the system is not powered, you can disregard the blue LED and thus skip the respective step. In that case it is a purely mechanical procedure.

1. To extract the active shelf manager initiate a switchover. Otherwise continue with the next step.
2. Put on an ESD wrist strap.
3. Connect the strap to the shelf by attaching it to the front or rear ESD jack /ESD snap.
4. Remove any cables that are attached to front panel connectors.
5. Unfasten the screws of the face plate until the handle is detached from the front panel of the board. The handle switch activator triggers the blinking of the blue LED. The hotswap state remains in the state "extraction pending", so that the blue LED is still blinking.
6. Wait until the blue LED is illuminated.
7. Remove the board from the shelf using the extraction handles



Technical Assistance

For technical assistance or to report product damage or shortages, contact your local SMART Embedded Computing sales representative or visit <https://www.smartembedded.com/ec/support/>

Get More Information



For more information on this product, see the *Centellis 2x00 User Card-10GE Installation and Use* manual and other related technical documentation, which can be found by using the Documentation Search at <https://www.smartembedded.com/ec/support/>.



© 2020 SMART Embedded Computing™, Inc. All rights reserved. The stylized “S” and “SMART” is a registered trademark of SMART Modular Technologies, Inc. and “SMART Embedded Computing” and the SMART Embedded Computing logo are trademarks of SMART Modular Technologies, Inc. All other names and logos referred to are trade names, trademarks, or registered trademarks of their respective owners. These materials are provided by SMART Embedded Computing as a service to its customers and may be used for informational purposes only. For full legal terms and conditions, visit www.smartembedded.com/ec/legal.