

AXP640/AXP640-C03-AC Quick Start Guide

P/N: 6806800N13E-RevB March 2020

1 Box contents

Make sure you receive all items of your shipment:

- One AXP640/AXP640-C03-AC shelf
- One printed copy of Quick Start Guide (this document)
- One printed copy of Safety Notes Summary
- Any other items you ordered



When installing or servicing the system or accessories, strictly observe the safety precautions in the *Safety Notes Summary*. Ignoring these instructions can void the system warranty and cause personal injury or property damage.

2 ESD

Use ESD protection



Electrostatic discharge and incorrect installation or removal of the card can damage circuit or shorten its life.

Use a properly grounded ESD wrist strap or work in an ESD-safe environment.

Connect to the ESD connector at the front or the rear of the system.

3 Site preparation

1. Make sure that all environmental and power requirements defined in the *AXP640 Installation and Use* manual are met.
2. Operating temperatures refer to the temperature of the air circulating around the blade and not to the actual component temperature.

You will need the following to install the AXP640/AXP640-C03-AC six-slot shelf into an approved EIA 23" or 600mm x 600mm ETSI frame:

- Torque wrench
- Nut driver with 7/16mm socket
- Multimeter
- Phillips head screwdriver, #1
- Front mounting brackets for an EIA 23" frame

4 Mount the shelf

Instructions for a 23" EIA Rack/Cabinet

Front mounting brackets are required to attach the shelf to an EIA 23" frame.

1. Locate the standard mounting hole and slot locations on the front mounting flanges on the AXP640/AXP640-C03-AC shelf.
2. Fasten the mounting brackets to the back side of the front chassis flanges using M6 x 12mm screws at each of the four locations.
3. Make sure to mount the shelf with metal screws or bolts that give a good electrical connection between the screws or bolts and the mounting surface.
4. Tighten all screws using a torque setting of 35.5 to 38.5 inch-pounds.

Instructions for a 600mm ETSI Rack/Cabinet

The shelf mounts directly from the integrated flange on the front of the shelf.

1. Locate the standard mounting hole and slot locations on the front integrated mounting flanges on the shelf.
2. Fasten the mounting brackets to the back side of the front chassis flanges using M6 x 12mm screws at each of the four locations.

3. Mount the shelf with metal screws or bolts that give a good electrical connection between the screws or bolts and the mounting surface.
4. Tighten all screws using a torque setting of 35.5 to 38.5 inch-pounds.

Refer to the *AXP640 Installation and Use* manual for additional information.

5 Ground the shelf

1. Use a 16 AWG wire with a 2-hole copper lug. The 2-hole lug prevents rotation of the lug and ensures a permanent bonding of ground to the shelf.
2. Connect the wire directly to the earth ground point located on the right side of the rear of the shelf.
3. Connect the other end of the wire to a reliable earth ground.
4. Tighten the lug bolts using the torque setting required by the connector supplier.
5. Connect to power feed.

6 AC power cable

Power is introduced to the shelf at the AC inlet located at the rear side of the shelf. The recommended power cable is a 14 AWG gauge that meets the specifications for this shelf.

There is one IEC connector for each power supply.

7 Connect the power cable

1. If you are not in an ESD safe environment:
2. Put on an ESD wrist strap and connect the strap to the system by attaching the rear ESD jack/ESD snap.
3. Make sure the external power feeds that you plan to attach are powered off and cannot be switched on while you are working.
4. Locate the target power input cable's terminals at the branch circuit or power distribution unit.
5. Lock and tagout the circuit breakers on the branch circuit.
6. Attach the AC power cables to each IEC input connector.



8 Power up the shelf

1. Break the tagout or lockout seals on the branch circuit or power distribution unit.
2. Apply power by closing the branch circuit or power distribution unit.
3. Verify that all FRU LEDs illuminate and the PSU In Service LED is green.

The system executes its normal start-up routine and is then ready to use.

Technical Assistance

For technical assistance or to report product damage or shortages, contact your local SMART Embedded Computing sales representative or visit <https://www.smartembedded.com/ec/support/>

Get More Information



For more information on this product, see the *AXP640 AdvancedTCA Shelf Installation and Use* manual and other related technical documentation, which can be found by using the Documentation Search at <https://www.smartembedded.com/ec/support/>.



© 2019 SMART Embedded Computing™, Inc. All rights reserved. The stylized “S” and “SMART” is a registered trademark of SMART Modular Technologies, Inc. and “SMART Embedded Computing” and the SMART Embedded Computing logo are trademarks of SMART Modular Technologies, Inc. All other names and logos referred to are trade names, trademarks, or registered trademarks of their respective owners. These materials are provided by SMART Embedded Computing as a service to its customers and may be used for informational purposes only. For full legal terms and conditions, visit www.smartembedded.com/ec/legal.